

PRODUCT INFORMATION

DIGITAL FLOW METER

NEW



((



Various applications from in-line test to lab use.

Large LCD screen displays a lot of info besides flow.

Accuracy ±1% of reading supported.

* Flow range: 1 L/min or more

■ Features



Easy-to-navigate configuration with icons Each menu opens by simply touching an icon.



Test pressure and flow can be monitored in charts.



Language selectable (English, Japanese, Chinese)



Various Hold functions Provides desired data.



Easy data collection via USB port.




Full 4-digit display



FTP available for Ethernet. (When the Memory is selected)

■ Application Examples

- High-accuracy flowmeter for labs
- Flow and leak tests for auto parts
- Flow test for gas equipment
- Flow test for valves
- Flow test for medical devices
- Flow test for pumps and pipes
- Others





Measurement screen can be selected from "Advanced", "Waveform", and "Simple"







English, Japanese, and Chinese





 Large numeric keyboard pops up for easy test parameter settings.




• Temperature, Line Pressure and Atmospheric Pressure Sensors provided. Compensation features realize higher accuracy.





• The sensors can be calibrated.


Various Hold functions



"Direct Hold", "Max Value Hold", "Min Value Hold", and "Peak-to-Peak"

• Test parameters and results can be output to the USB memory.







■ Features


Color LCD Touch-Screen	From the Main Menu, sub menus "Measure Screen", "Settings", "System", "Comp", "Analysis", etc. are accessible.	Language	English, Japanese, Chinese
Measure Screen	Can be selected from "Advanced", "Waveform", and "Simple".	Flow Range	10 mL/min to 500 L/min
Settings	Tap the items on the touch screen.	Sensor	Temperature Sensor, Line Pressure Sensor and Atmospheric Pressure Sensor provided as standard.
Flow Limits	Two sets of leak limits: Upper limits (UL2/UL), Lower limits (LL2/LL)	Conversion Temperature	0 °C, 15 °C, 20°C, 25 °C, (70 °F)
Flow Display	Converted flow rate (Value converted to volume at 1 atm at conversion temperature)	Digital Filter	The filter constant (1 to 50) averages the display values which gives stabler measurement.
USB Port	Provided as standard (1 port)	User Span	Adjusts to desired flow rates.
RS-232C	2 ports as standard Compatible with DF-2820	Internal memory	16 G for Ethernet (Option)

■ Specifications

-p			
Flow Sensor	Laminar Flow Sensor (Laminar Flow Tube)		
Pressure Media	Air		
Flow Range	Up to 16 ranges for 8 Laminar Flow Tubes		
Atmospheric Pressure Sensor	Range: 700 to 1200 hPa Accuracy: ± 0.5% of F.S. + 1digit		
Line Pressure Sensor	Proof Pressure 50 kPa or less: F.S. Range x 10 100 kPa or more : F.S. Range x 2 Accuracy: ± 0.2% of F.S. + 1digit		
Number of Channels	100 channels (0 to 99)		
Flow Unit	mL/min, L/min, mL/s, L/s, L/h, m³/h, (CFH, CFM) The units in () are not available for SI unit models.		
Pressure Unit	kPa, MPa, (PSI, kg/cm 2 , Bar, mbar, mmHg, cmHg, inHg, mmH $_2$ O) The units in () are not available for SI unit models.		
Power Source	100 to 240 VAC ±10%, 50/60 Hz,100 VA max Select 125 V or 250 V		
Option	Analog Output	Flow rate + Line pressure	
Option	Internal memory	16 G (For FTP)	

Line Pressure Compensation	Automatic compensation with pressure sensor		
Atm Pressure	Automatic compensation with atmospheric		
Compensation	pressure sensor		
Operating Temperature	5 to 45 °C		
Humidity	80 % RH or less / No dew condensation		
Differential Pressure Port Size	Rc1/8		
Weight	Approx. 8.2 kg		
Dimensions (mm)	(W) 283 x (H) 189 x (D) 382		
	Two-way communication	Data calling and writing	
	Fixed length output	DF Format (Various data)	
RS-232C		28 Format Same format as for DF-2800	
	Baud rate (bps)	1200, 9600, 19200, 38400, 57600, 115200	
USB	Data storage, writing, backup, etc.		
LAN	FTP installed		
Interface	Phoenix Contact (DFMC 1,5/20-ST-3,5-LR)		
Standard Accessories	Quick Mounting Brackets, Connectors, Inspection record, Traceability documents, Operation manual, Power cord, Fitting/Piping for connecting differential pressure		

■ Model **DF-R280-A.BB'CD-E-F** (Conversion temperature, Flow range-Unit, Accuracy, Line Pressure Sensor)



See the "Flow Ranges" below for flow ranges.

For 1 L/min or above ranges:

2-range calibrations (L Range and U Range) are available. (The price for the calibration of L Range will be charged separately.)

Ranges of Line Pressure Sensor

10 kPa, 50 kPa, 100 kPa, 500 kPa, -100 kPa

UX3 in preparation *1

	Classification	Code	Function	
A	Number of Laminar Flow Tubes	1 to 8	Number of Laminar Flow Tubes	
BB'	Laminar Flow Tube Range	10ML to 500L	Enter all the ranges.	
		L01	1 to 10 kPa	
	Line Pressure Sensor	L05	10 to 50 kPa	
c		L	10 to 100 kPa (Standard)	
		М	30 to 500 kPa	
		V	-10 to -70 kPa	
D	Ontion	Α	Analog output (Flow, Line pressure)	
	Option D	Memory 16 G (For FTP)		
		UX1	SI units (Mandatory for Japan)	
E	Unit (Mandatory)	UX2	All units (Only for overseas)	
		UX3	All units (Only for UL) *1	
	Power Cord	VA	125 V (3 m)	
B		VE	250 V (2 m)	
	rower cord	VK	250 V (2 m) (Only for Chinese	
			customers)	

^{*} Please contact us for other ranges.



Laminar Flow Sensor (Laminar Flow Tube)



- Select from many ranges. F.S.10 mL/min to 500 L/min
- Can measure pulsating flow such as pump discharge flow.
- Same performance as the flow sensors used in the conventional DF-2820/2810.
- Robust and durable with no moving parts.

■ Flow Ranges (Laminar Flow Tube are sold separately)

Code	Model	Rang	es and number of display	/ digits	Line pressure (Max.)	Accuracy
10ML	LF-104N-10C		0.00 to 10.00 mL/min			
20ML	LF-104N-20C		0.00 to 20.00 mL/min			At atmospheric pressure:
50ML	LF-104N-50C		0.00 to 50.00 mL/min		990 kPa ±1.0 % of F.S.±1 digit At Line pressure:	
100ML	LF-104N-100C		0.0 to 100.0 mL/min			
200ML	LF-104N-200C		0.0 to 200.0 mL/min			±1.5% of F.S.±1 digit
500ML	LF-104N-500C		0.0 to 500.0 mL/min			
Code	Model	1-range (F.S) accuracy range & Display digits	L Range & D isplay digits	Accuracy range (R.D.) U Range & D isplay digits	Line pressure (Max.)	Accuracy
1L	LF-104N-1L	0.000 to 1.000 L/min	0.000 to 0.300 L/min	0.300 to 1.000 L/min		■ 1 range (R.D) / U Range
2L	LF-104N-2L	0.000 to 2.000 L/min	0.000 to 0.600 L/min	0.600 to 2.000 L/min	700 kPa	At atmospheric pressure:
5L	LF-104N-5L	0.000 to 5.000 L/min	0.000 to 1.500 L/min	1.500 to 5.000 L/min		±1.0 % of rdg. ±1 digit
10L	LF-104N-10L	0.00 to 10.00 L/min	0.000 to 3.000 L/min	3.00 to 10.00 L/min		At Line pressure:
20L	LF-104N-20L	0.00 to 20.00 L/min	0.000 to 6.000 L/min	6.00 to 20.00 L/min	500 kPa	±1.5 % of rdg. ±1 digit
30L	LF-104N-30L	0.00 to 30.00 L/min	0.000 to 9.000 L/min	9.00 to 30.00 L/min		■ 1 range (F.S.) / L Range
50L	LF-105BN-50L	0.00 to 50.00 L/min	0.00 to 15.00 L/min	15.00 to 50.00 L/min	350 kPa	At atmospheric pressure:
100L	LF-105BN-100L	0.0 to 100.0 L/min	0.00 to 30.00 L/min	30.0 to 100.0 L/min	200 kPa	±1.0 % of F.S.±1 digit
200L	LF2-200L	0.0 to 200.0 L/min	0.00 to 60.00 L/min	60.0 to 200.0 L/min	50 kPa	At Line pressure:
500L	LF2-500L	0.0 to 500.0 L/min	0.0 to 150.0 L/min	150.0 to 500.0 L/min	JU KFA	±1.5 % of F.S.±1 digit

Note 1: The above ranges are the flow ranges at atmospheric pressure.

Note 2: For the Laminar Flow Tubes whose model name has "N" in it, new temperature sensor connectors are being used from April 2011.

Note 3: For single range (1 range) Laminar Flow Tubes of 1 L/min or above, the accuracy of "0 to full range (F.S.)" or "30% to full range (R.D)" can be selected.


Note 4: For Vacuum and High Line Pressure (101KPa or more) models, the range of Laminar Flow Tube will be different.


Note 5: When the range is 10C, the value of small flow fluctuates due to the relational equation with the pressure. Use a smaller number of display digits in that case.

■ Option


Analog Output


Analog values of flow and Line pressure Can amplify up to 10 V





■ External Appearance





^{*} The contents in this Product Information are as of January 2022. The specifications are subject to change without prior notice.

Cosmo Instruments Co., Ltd.

2974-23 Ishikawa, Hachioji, Tokyo 192-0032 Japan

		-
China:	Cosmo (Shanghai) Trading Co., Ltd.	+86-(0)21-6575-6880
	Shanghai, Tianjin, Guangzhou, Chongqing, Changchun, and Wuha	an
Korea:	Cosmo Korea Co., Ltd.	+82-(0)32-623-6961
Taiwan:	Taiwan Cosmo Instruments Co., Ltd.	+886-(0)2-2707-3131
Malaysia:	COSMOWAVE SDN.BHD.	+60-(0)3-51626677
Thailand:	Cosmowave Technology Co., Ltd.	+66-(0)2-7361667
Indonesia:	Pt. Cosmowave	+62-(0)21-42900043
Vietnam:	Cosmowave Technology Co., Ltd. Vietnam Representative Office	+84-(0)47876085

http://www.cosmo-k.co.jp/

Phone: +81-(0)42-642-1357 Fax: +81-(0)42-646-2439

	()	
India:	Cosmo Instruments India Pvt. Ltd. Head Office	+91-(0)124-421-0946
	Cosmo Instruments India Pvt. Ltd. South Zone Regional Office	e +91-(0)9663384423
	Cosmo Instruments India Pvt. Ltd. Pune - Chakan Office	+91-(0)20-6933-2345
	Cosmo Instruments India Pvt. Ltd Chennai Office	+91-(0)9994364454
Germany:	Cosmo EU Solutions Technology GmbH	+49-(0)212-383671-71
USA:	Cosmo Solutions Technology, Inc.	+1-248-488-2580
Mexico:	Cosmo De Mexico	+52 472 748 62 94
Brazil:	Tex Equipamentos Eletronicos Ind. Com. Ltda.	+55-(0)11-4591-2825
Australia:	Industrial Research Technology Pty. Ltd.	+61-(0)412-176-674